

Land Rover HSE Packing List

Legs

- 6 * L. mounting brackets
- 6 * Slotted brackets bolted to base of L. bracket
- 18 * Countersunk 15*6mm bolts
- 18 * 6mm Nvloc nuts
- 18 * 6mm washers

Bed

- 1 * rack bed
- 6 * (8*30mm) bolts
- 6 * 8mm Nyloc nuts
- 12 * 8mm washers



- 1 * back rail
- 2 * side rails
- 16 * countersunk 15*6mm bolts
- 16 * 6mm nylock nuts
- 16 * 6mm washers

Top Rail assembly:

- 1. Slide firstly 1 of the 6.15mm, then 4 of 6*12mm bolts into each channel on the top of the tubing on the sides on the rack. The very first one, slide all the way forward this will be used to fasten the front of the top rail to the rack at a later stage.
- 2. Slide 4 of 6*12's into the underside of each top rail, as well as the back curved one.
- 3. Attach 2 stainless u channels to both sides of the rack the back one should be positioned so
- that it overlaps with half of the rear rail, and half on the side rail position the join in the middle. Position the front one midway between the rear and the front of the side rail. Mount the side rail on top of these plates, bolting the front down with the one bolt you left right in the front of the rack. Tighten all in place(keep loose for minor adjustment), repeat for back rail and other side rail.
- 4. Tighten all nuts.







Fitment:

- 1. Remove rack from carton
- 2. Assemble top rail as per instructions.
- 3. Slide open rack mounting slots in black strip on vehicle roof.
- 4. Assemble L-Bracket leg set keeping bolts as loose as possible.
- 5. Place in position in mounting slots, nuts facing inwards.





- 6. Tighten leg mounting bolts.
- 7. Place basket on legs line up with 50*6mm flat bar sections on basket.
- 8. Once lined up and the rack is square on vehicle, drill one 8mm hole through centre of 50*6mm plate, through the L-Bracket leg section.
- 9. Insert 8mm bolts and tighten.



Important:

Check all nuts and bolts periodically to ensure not have loosened.

HANNIBAL SAFARI EQUIPMENT SOUTH AFRICA

Telephone: +27 21 534 9050 Fax: +27 21 534 9053 email: info@hannibal.co.za Web: www.hannibal.co.za